

Title: Configure IP address to routers in packet tracer. Explore the following messages: ping responses, destination unreachable, request timed out, reply




Topology with single router

Pinging PC2 from PC1



```
20.0.0.2
                                                                                    ×
Physical
           Config
                    Desktop
                               Custom Interface
  Command Prompt
   Packet Tracer PC Command Line 1.0
   PC>ping 10.0.0.1
   Pinging 10.0.0.1 with 32 bytes of data:
   Reply from 10.0.0.1: bytes=32 time=0ms TTL=127
   Ping statistics for 10.0.0.1:
   Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds:
       Minimum = 0ms, Maximum = 0ms, Average = 0ms
   PC>
```

Pinging PC1 from PC2



Topology with 3 Routers


Pinging end device in different network before setting IP route


```
₹ PC2
                                                                                                                                             ×
                                Desktop Custom Interface
Physical
                 Config
     Command Prompt
                                                                                                                                                 Χ
      Packet Tracer PC Command Line 1.0 PC>ping 20.0.0.1
      Pinging 20.0.0.1 with 32 bytes of data:
     Reply from 20.0.0.1: bytes=32 time=0ms TTL=255
     Ping statistics for 20.0.0.1:


Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms
      PC>ping 40.0.0.1
      Pinging 40.0.0.1 with 32 bytes of data:
      Request timed out.
Request timed out.
Request timed out.
      Request timed out.
      Ping statistics for 40.0.0.1:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
```

IP route for all routers







After setting IP route

Pinging PC4 from PC2

```
₹ PC2
                                                                                                                         X
Physical
               Config Desktop Custom Interface
     Command Prompt
                                                                                                                                  Χ
            Minimum = Ums, Maximum = Ums, Average = Ums
      PC>ping 40.0.0.1
     Pinging 40.0.0.1 with 32 bytes of data:
      Request timed out.
     Request timed out.
     Ping statistics for 40.0.0.1:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
      PC>ping 40.0.0.1
     Pinging 40.0.0.1 with 32 bytes of data:
     Reply from 40.0.0.1: bytes=32 time=2ms TTL=253
Reply from 40.0.0.1: bytes=32 time=8ms TTL=253
Reply from 40.0.0.1: bytes=32 time=5ms TTL=253
Reply from 40.0.0.1: bytes=32 time=7ms TTL=253
     Ping statistics for 40.0.0.1:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 2ms, Maximum = 8ms, Average = 5ms
```

Pinging PC2 from PC4

```
Physical Config Desktop Custom Interface

Command Prompt

Packet Tracer PC Command Line 1.0
PC-ping 10.0.0.1 with 32 bytes of data:

Reply from 10.0.0.1: bytes=32 time=2ms TTL=253
Reply from 10.0.0.1: bytes=32 time=7ms TTL=253
Reply from 10.0.0.1: bytes=32 time=6ms TTL=253
Reply from 10.0.0.1: bytes=32 time=6ms TTL=253
Ping statistics for 10.0.0.1:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 2ms, Maximum = 7ms, Average = 5ms
PC>
```